


## Connecting AVer Visualizers with Interactive Whiteboards and Projectors



### Steps

1. Connect the projector (VGA In) and Visualizer (VGA / RGB Out) with a VGA cable
2. Connect the Visualizer (VGA / RGB In) and computer (VGA Out) with a VGA cable
3. Connect the computer and Visualizer with a USB cable.
4. Connect the computer and Interactive Whiteboard with a USB cable
5. Launch the software for your IWB and then access the AVerVision Flash Plug-in by inserting it into the IWB software as you would a Flash (.swf) file

### NOTE:

1. Download the AVerVision Flash Plug-in from AVer's online download center ([presentation.aver.com/download-center](http://presentation.aver.com/download-center)) and install it on your computer
2. Switch between the input image from the Visualizer and the computer by pressing the PC / Camera button on the Visualizer
3. For AVerVision355AF, AVerVision F50 and AVerVision F30, to view images from the Visualizer on your computer, please toggle the USB OTG switch (Fig. 1) to PC and TV / RGB switch (Fig. 2) to TV



Fig. 1



Fig. 2