



Quick Guide: Connecting AVer NDI Cameras to Zoom Rooms®

Supported AVer Camera Models

- **PTZ Series:** PTZ211, PTZ231, PTZ310U(N)V2, PTZ330U(N)V2
- **TR Series:** TR211, TR315(N), TR335(N), TR535(N), TR615

Network Requirement

✓ Ensure that the AVer camera and the Zoom Rooms® system are on the **same network**.

Important Note

⚡ All AVer cameras come with the **NDI SDK preloaded**. No additional configuration is required to enable NDI.


Step-by-Step Setup

1. Open Zoom Rooms® Settings

- On your Zoom Rooms® controller or system, go to **Settings**.

2. Select Camera

- Click on **Camera**.
- The default camera will display as the **USB camera**.





3. Switch to Network Video Device

- Choose **Network Video Device**.
- Check your AVer NDI camera in the list and complete the settings.

The screenshot displays the AVer settings application. On the left, a sidebar contains navigation icons for Home, Contacts, and Settings. The main 'Settings' menu is open, with 'Camera' selected. The 'Camera' settings page is titled 'Network Video Device' and features a search bar. Below the search bar, it indicates 'Select up to 1 device(1 selected)'. The selected device is 'AVER (TR535N_Edd_PTZ) (Default)'. A list of 14 NDI devices is shown below, including 'AVER (TR535N_Edd_Wide)' and several 'DESKTOP-NCBVMS5 (ACG_PV_Eddie - video X)' devices.